Classy Caps

Lighting Instructions

How Your Solar Powered Post Cap Works

- The solar panel converts sunlight energy into electricity during the day. The photocell automatically turns the light on at night with the electricity stored in the batteries. It requires no wiring, because it runs off the sunlight energy to recharge the batteries so there is no cost to run the solar cap.
- The number of hours the light stays on depends on your geographical location, weather conditions and seasonal sunlight availability.
- Easy "Do-It Yourself" installation.

Includes:

- 1- Solar Post Cap Light
- 1- AA Ni-MH Rechargeable Battery
- 1- 2x2 adapter

Post Cap Installation

- 1) Twist the solar lid counter clockwise to remove from cap base as shown (fig.1).
- 2) Turn the auto / off switch to auto and twist the lid back into place.
- 3) Firmly push 2x2 adapter into cap base if required.
- 4) Press firmly down on the four corners of the fixture to secure cap to post.
- An exterior grade caulk may be applied to the bottom inside edge of the fixture before installation for added security.
- 6) Allow at least 8 hours of sunlight to fully charge the battery.

To Replace The Battery (battery replacement is approximately 1-2 years)

- 1) Twist the solar lid counter clockwise to remove from cap base as shown (fig.1).
- Replace the battery with new AA size 1.2 V Ni-MH rechargeable battery. Be sure to insert batteries in the proper direction.
- 3) Twist the lid back into place.
- 4) Allow the fixture to receive a full 8 hours of sunlight to allow the rechargeable batteries to reach maximum capacity.

Troubleshooting

If the light does not turn on at dusk after 8 hours of charging:

- Check the batteries to make sure they are making secure contact with the terminal.
- Be sure the solar fixture is in a relatively sunny location.
- Make sure the light's photocell is not affected by other light.

Maintenance

Periodically clean light fixture with soft cloth and warm soapy water.

One Year Limited Warranty

This product is warranted to be free from defects in workmanship or materials at the time of purchase for one year, (excluding batteries). Should a defect occur, please contact our customer service line at 1-866-460-4604 for service. Should any evidence of defects in material or workmanship appear within the warranty period after the date of purchase, Classy Caps Mfg. Inc. will either repair or replace the product at its option.

Classy Caps Mfg. Inc. is not responsible for injury, property damage, or other consequential damages or damages to third parties arising directly or indirectly from an actual or alleged defect in material or workmanship of the product.

