


Introduction

Thank you for your purchasing a COCO Bluetooth® Remote Control. COCO Bluetooth® Remote Control allows you to control multiple applications on your iOS or OS X devices with the latest Bluetooth® technology.



Features:

1. Control playback of your music and video;
2. Take photos and record videos without leaving yourself out and eliminate any camera instability;
3. The Home button of the remote can be used to activate Siri;
4. A presenter for Mac PCs;

1

Specifications

Frequency: ISM Band 2.4 GHz
 Bluetooth Version: 3.0HID, Class 2
 Power Supply: Coin Cell (CR2025×1)
 Connecting Time: 60sec
 Sleep: 10min
 Range: approx. 35ft
 Battery Life: 1×CR2025 Battery approx. 3months(based on 1 hour of use/day)

Contents

- 1×COCO Bluetooth® Remote Control
- 1×CR2025 Battery
- 1×User Manual


Operating System

iOS or Mac OS X version 10.4 or later

Replacing the battery

Insert one CR2025 battery into the battery compartment of the device before use. Ensure that the positive and negative terminals of the battery and the compartment are matched.

2




Bluetooth Pairing

Bluetooth pairing is required before the first use with the device.

1. Turn the device on—press the "ON/OFF" Button until the green LED light stops flashing.
2. Press the "Bluetooth Connect" button until the LED light flashes in red and green indicating it's in pairing mode;


3

3. In your Apple device, go to Settings > General > Bluetooth and ensure that Bluetooth is on;




4

4. Select "CC Remote" from the Device



5

5. If pairing is successful, your Apple device will display "Connected" on the Bluetooth devices list.




6

6. Turn the device off—press the "ON/OFF" Button until the red light turns off.


The Bluetooth Remote for iOS can be paired to a MAC with bluetooth to control: Music, Presentations in keynote, Photo and Video Playback.

1. Access your Mac's Bluetooth settings by clicking the Bluetooth icon on the desktop or in the system bar. Select "Turn Bluetooth On" to activate the Bluetooth function.
2. Scroll down the list and select "Set up Bluetooth Device..."
3. The Bluetooth Setup Assistant will begin—follow the on-screen instructions.
4. Press the "Pair" button on the right side of the remote to put it into pairing mode. Select "CC Remote" from the list and click continue to proceed with setup.



7

5. Your CC Remote is ready to be used.



Note:

1. On your Apple device, the Remote Control may be recognized as an independent keyboard causing the normal Apple keyboard screen not to appear. If this is the case, press the Keyboard button on the remote to activate the keyboard screen. Once the remote is powered off, the keyboard screen will automatically appear on your device.
2. When not use, the device should be turned off to save battery.
3. Not work with Keynote on iOS devices

8

FCC ID

This device complies with part 15 of the FCC results. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference.
 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different

9

from that to which the receiver is connected.

- Consult the dealer or an experienced radio/television technician for help.

Limited Warranty:

COCO warrants this product to be free from defects in materials and workmanship for 1 year. If this product is found to be defective within the time, we will repair or replace it. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. Under no conditions is COCO liable for loss of, or damage to devices; nor loss of, or damage to programs, records, or data; nor any consequential or incidental damages, even if COCO has been informed of their possibility. This warranty does not affect your statutory rights.

10



COCO Bluetooth® Remote Control
 media control+camera remote shutter+Siri+Presentation

User Manual

CC-PC101