

Courtesy of LumaPower enthusiast Ernest Sanada are these instructions and photographs for switching tail caps with the LumaPower D-Mini & M1

This is how you change the supplied momentary on off twist on and twist off switch to the reverse clickie switch or 2 stage switch. These instructions show the D-Mini but the process is identical with the M1.

A view inside of the on off twist switch.



Push out the switch through the rear by pushing on the rubber switch cover.



There is another piece inside the switch. Note the 2 notches.



Use a pick/toothpick/tweezers, etc put it in one of the notches. Remember righty tighty lefty loosey and remove the black plastic unit. Turn lefty loosey, counter-clockwise.



The plastic assembly comes out with the rubber switch cover.



Now you can change the black rubber switch cover to the GITD if desired or replace/leave the black rubber switch cover in.



Put the reverse clickie switch in. Righty tighty, turn clock-wise.



Use a pick to tighten the switch.





Now it's time to enjoy your D-Mini/M1 tail cap switch! This process is very easily reversed to return to the tactical/momentary switch.

