

Instructions for **Tiablo A9** LED flashlight

Profile

- I..... Specifications
- II..... How to install the flashlight with illustration
- III..... Accessories, after sale service and warranty
- IV..... Frequently Ask Questions



I. Specifications

1. Cree 7090 XR-E LED.
2. Step down constant current driver, High efficiency with dual mode DC-DC regulator (PWM / PFM), working voltage is 2.7V to 10V. Replace battery when the light is too dim.
3. Two stage output.
 - High output: 1A at maximum 256 Lumens for about 3.5 hours
 - Low output: 300mA at 60 Lumens for 8 hours
4. 42 mm diameter x 33 mm deep reflector provides greater efficient illumination over longer distances than the standard with similar power..
5. Supports three sizes battery, one 18650 Li-ion battery, two pcs CR123A or RCR123A battery.
6. Type-III hard anodize. Aircraft aluminum T7075.
7. Two color: Natural HA-III and Olive Drab.
8. Water proof to 5m/15ft.
9. Toughened ultra clear glass lens with AR coating.
10. Tactical clicky switch: Low-High-Off.
11. Length 158mm, Head diameter: 45mm, Weight: 155g (battery excluded)
12. Stand by as candle.
13. Anti-falling ring to make it safer to put on desk or table.

II. How to install the flashlight with illustration



All Tiablo flashlights are assembled by Tiablo factory and with strict quality control; users only need to screw off the tailcap, put the batteries in the housing, (anode towards head) and screw on the tailcap, then can click the tailcap to light up.

III Accessories, after sale service and warranty

Accessories: Instructions, three pcs O-ring, one pcs black and one pcs glow press button cap.

Option part: SMO or OP reflector

After sale service and warrantee: Any quality problem, can be replaced or refund without any condition.

Three years warranty, improper usage excluded

IV FAQ

Remark:

1. Battery anode towards head, or LED will be burnt.
2. Do not touch inside of the reflector
3. Please use the right batteries according to the instructions.
4. If do not use the flashlight, take out the battery to keep the housing dry.
5. Do not disassemble the circuit, otherwise no warranty.

FAQ:

1. Put battery in and screw tailcap on, but no light? Please check if have put battery in wrong direction, battery is empty or not, voltage too high or too low, or not right battery for the flashlight at all.
2. The light flickers? Please check if any connection parts are loose.
3. Other problems, kindly contact us or our local distributors, we will solve it.

Thank you for choosing Tiablo, your satisfaction is our proud.

www.tiablolight.com