



Finding a new PowerTap Hub

FAQ: I just purchased a wheel with a PowerTap hub, but my PowerTap computer isn't finding the hub! What should I do?!?!

Answer: *This happens because the PowerTap computer can only store one 5-digit code at a time. Each PowerTap hub has a unique code that is broadcasted therefore the computer needs to learn this new code. Here are the steps to accomplish this:*

When using a different hub you will need to learn the code that the hub is broadcasting. To accomplish this you should do the following:

1. *Spin the rear wheel to wake the hub out of sleep mode.*
2. *Hold down MODE + SELECT till you see a screen that says "SEE EDt" with numbers 1-5 at the bottom. These are menus.*
3. *Press SELECT till the number 5 is flashing*
4. *Press MODE*
5. *You are now on a screen that shows the HUB ID, which is a 5 digit code. It is set to the last hub your PowerTap computer was talking too.*
6. *Press MODE, which scrolls through the numbers (you can manually set the numbers by pushing SELECT), till you see the word LEARN*
7. *Hold down SELECT till LEARN starts flashing. Let go of SELECT. Your computer will now find the hub and store the 5-digit code!*
8. *Continue to press MODE till you exit the Menu*
9. *Go out and put the power down!!!*