

Adding Local User Accounts through the Web UI

Web Redirection

Basic	
Functionality:	Enabled with Authentication
Encryption method:	401 Authorization
Authentication protocol:	Local Accounts
Account Mode:	Time to finish
Authentication login page:	Accumulate
<input checked="" type="radio"/> Default login page	Time to finish

Figure 1

Step 1:

Select **AAA -> Web Redirection**. When settings “Functionality” and “Authentication protocol” are set to *Enabled with Authentication* and *Local Accounts* respectively, the option “Account Mode” will appear as seen in Figure 1. The two possible selections for “Account Mode” are *Accumulate* and *Time to finish*. The following is a description of the two settings:

Accumulate – Accounts expire after the user has logged in for x amount of time.

Time to finish – Accounts expire after x amount of time after account creation.

Select mode that you desire.

Ticket Setting

Title of list:	Hotspots Logo
Name of supplier:	Company Name
Web of supplier:	www.company.com
Phone number:	0800-012345
Monetary unit:	Unit
Amount of money per unit:	10.00
Unit of session time (min.):	1
<input type="checkbox"/> Print wireless information (SSID, security method and encryption key).	

Figure 2

Step 2:

Go to **AAA -> Ticket Setting**. In this section (as shown in Figure 2), enter the information for your ticket settings. The main settings to pay attention to are the “Amount of money per unit”, “Unit of session time (min.)” and “Print wireless information”. The following is a description of each setting:

Amount of money per unit – Sets the amount of money each unit costs.

Unit of session time – Sets the amount of minutes each unit represents.

Print wireless information – When you enable this setting, the wireless SSID, security method and encryption key will be printed on the ticket from the printer.

No.	User Name	Pass word	Mac Address	Session(min.)	Remaining(min.)	Valid Time(min.)	Cost	Status
11	test2	1234	FFFFFFFFFFFF	20	0	-	200	Inactive
12	test7	1234	FFFFFFFFFFFF	20	0	-	200	Inactive
13	test10	1234	FFFFFFFFFFFF	20	0	-	200	Inactive
14	test16	1234	FFFFFFFFFFFF	20	0	-	200	Inactive
15	test11	1234	FFFFFFFFFFFF	20	0	-	200	Inactive
16	test19	1234	FFFFFFFFFFFF	10	0	-	100	Inactive
17	dkKuFj2CK	5IE5H2D2p	FFFFFFFFFFFF	510	0	-	5100	Inactive
18	vnavYc2aH	s2fhqFd2q	FFFFFFFFFFFF	10	0	-	100	Inactive
19	VlHwGy2HV	UF5pyw8ab	FFFFFFFFFFFF	1	0	-	10	Inactive

Figure 3

User name: Password: Unit:
(The maximum length for user name and password is 9 characters. 0 Unit stands for Permanent User.)

Figure 4




Figure 5

Step 3:

Go to **Status -> Account Table**. On this page displays the account information for all the accounts as seen in Figure 3. You can also add new or delete current user accounts from this page as shown in Figure 4. There is also the option to generate a user name and password for account creation by using the “Generate” button as seen in Figure 5. To create a user account, enter the “User name” and “Password” that you desire or if you wish to randomly generate it, press the “Generate” button. Then type in the amount of units for this user account. The amount of time and cost for each unit was determined in Step 2. After you are done, press the “Add” button and your account is created.