

05-08 Mustang Fuel Door Installation Instructions

1. Remove original fuel door using 7mm wrench or socket. Remove two rubber bumpers.
2. Install new door, making sure one nylon spacer is on the stud above the hinge.
3. Slide remaining three nylon spacers over studs from rear. Thread three flange nuts onto studs against spacers.
4. Tighten three flange nuts until tight. Do not over tighten.