



UPR Big Mouth Air Filter Cleaning Instructions

- 1.) Shake or tap the filter to remove any large particles of dirt/bugs/leaves that might have gotten trapped in the material.
 - 2.) Fill a spray bottle with 10% dish soap (Dove, Palmolive, etc...) and 75% tap water and coat the filter with the above cleaning solution so that the entire filter surface is covered sufficiently and let it soak for 8-10 minutes.
- OR**
- 2.) Fill a bucket with some dish soap (Dove, Palmolive, etc...) and tap water and place the filter into the bucket with the cleaning solution and let it soak for 8-10 minutes. This is the recommend way to clean the filter.
 - 3.) Rinse the air filter out with water from the inside of the filter pushing out any dirt. Do not use a pressure cleaner on the filter.
 - 4.) Once rinsed thoroughly shake the filter to get as much water out of it then let it dry. Do not use a hair dryer, compressed air or any other kind of heat source to dry the filter.
NOTE: If you have a stainless filter it does not use filter oil so the following steps do not need to be followed.
 - 5.) After the filter material is completely dry, spray filter oil onto the surface of the filter and let it sit for 15 minutes but make sure not to over oil it. After it has sat check the material to make sure it is covered, if not hit the spots that were missed.
 - 6.) Once the filter surface has an even coat on it then you can re-install filter back into car.

For performance applications it's recommended to clean the filter every 20,000 miles to ensure optimum performance. In normal street applications it's recommend to clean the filter every 50,000 miles or whenever the filter looks discolored from dirt. Although the filter will work fine past 50,000 miles it could hurt performance and the gas mileage of the vehicle.