

GONDOLA CANOPY & END PANELS

Canopy End Crowns extends 7" on the top beyond base shelf depth to properly allow for electrical lighting. Adjustable canopy brackets adjust from 16" to 28". Canopy brackets can be used with standard upper shelves to create closed canopy. (Canopy Brackets & End Panels are sold separately)
Standard Colors, White, Maple, & Cherrywood

Gondola Canopy End

Item#	Base Shelf Depth	Panel Depth
CE12	12"D	16"D
CE14	14"D	18"D
CE16	16"D	20"D
CE18	18"D	22"D
CE20	20"D	24"D
CE22	22"D	26"D
CE24	24"D	28"D

Gondola Canopy Facia

Item#	Description
GCF367	36"L x 7"D
GCF487	48"L x 7"D
GCF727	72"L x 7"D
GCF967	96"L x 7"D

Gondola Canopy Brackets

Item#
GCB



Adjustable Canopy Bracket
Extends from 16" to 28" for
Base Shelves with Depth from
12" to 24"



2" Radius End Panels Also Available



End Panels can be used to customize and enhance eye appeal in a gondola unit. They make a store look more attractive, adding color as well as enriching the color of the gondola unit. If you choose not to have a canopy, end panels are straight up all the way to the top (no top extension crown). They are available in any color.
Standard colors are cherrywood and maple.

Gondola End Panels

BASE SHELF DEPTH	12	14	16	18	20	22	24
UPRIGHT HEIGHT							
60	GEP6012	GEP6014	GEP6016	GEP6018	GEP6020	GEP6022	GEP6024
72	GEP7212	GBP7214	GEP7216	GEP7218	GEP7220	GEP7222	GEP7224
84	GEP8412	GEP8414	GEP8416	GEP8418	GEP8420	GEP8422	GEP8424
96	GEP9612	GEP9614	GEP9616	GEP9618	GEP9620	GEP9622	GEP9624