

USB Cradle – User Manual (version 1)

Specification:

- Charge your device via USB or A/C charger
- Device dock securely in cradle
- Synchronizes your device with PC / notebook computer
- Supports hi-speed USB 2.0 data transfer
- Includes a 110-240v A/C power input with LED indicator for fast charging
- Includes a USB cable that synchronizes and charges your device without an A/C adaptor cable
- 1-year warranty

Quick Guide:

To Sync your device with your computer:

- Put your device into the cradle, connect the cradle to your computer by the USB cable

To charge your device:

- Put your device into the cradle, connect the cradle to your computer by the USB cable; OR
- Put your device into the cradle, connect the cradle by an AC charger
(as different PDA/smartphone model requires different AC power level, please use our AC charger. Otherwise, please consult your supplier before using the AC charger)

To charge your spare battery: (only available for cradle with spare battery charging slot)

- Put your spare battery into the spare battery charging slot, connect the cradle by an AC charger
(as different PDA/smartphone model requires different AC power level, please use our AC charger. Otherwise, please consult your supplier before using the AC charger)

LED Indication:

USB sync / charge cradle:

Blue LED indicator is on when:

1. USB cradle is connected by USB cable to your computer
2. USB cradle is connected by AC charger (only)

USB sync / charge cradle with spare battery charging slot (2 LED indicators):

When cradle is connected by USB (to computer):

1. Both device and 2nd battery are not in the cradle:
"device light indicator": blue color
"spare battery indicator": no signal
2. With device in the cradle (2nd battery not in the spare battery charging slot):
"device light indicator": blue color
"spare battery indicator": no signal
3. When 2nd battery is in the spare battery charging slot:
"device light indicator": blue color
"spare battery indicator": no signal

When cradle is connected by AC charger (only):

1. Both device and 2nd battery are not in the cradle:
"device light indicator": blue color
"spare battery indicator": green and red color interchange flashing
2. With device in the cradle (2nd battery not in the spare battery charging slot):
"device light indicator": blue color
"spare battery indicator": green and red color interchange flashing
3. When 2nd battery is in the spare battery charging slot:
"device light indicator": blue color
"spare battery indicator": light indicator change to red (when charging) and when it is full charge, it changes to green