

STEPS TO PROGRAM THE LOCKS

1) Set lock System ID (12 Digit)



Note: Lock “System ID” is the combination of 8 digits “Facility Code” and 4 digits “Lock No.”

2) Set Lock Master Code (MC 4-9 Digit)



3) Set Lock Daylight Saving Time

Starts:



Ends:



Note: United State daylight saving time starts on the second (2) Sunday (0) in March (03) and ends on the first (1) Sunday (11) in November (11)

4) Set Lock Clock Time



Note: We use 24 hour clock format to define the hour, for example, if it's May 29, 2009 3:26PM, then you will enter: 0529091526