

ER-KP1 Wiring Diagram

Single 12VDC Power Supply Wiring Diagram

The ER-KP1 Reader Operates on a 12 Volt DC Power Supply and will only control a 12volt DC Latch/Strike.

Purchase a 12volt Power Supply Based on Your System Power Requirements

