



VORNADO®

SoleAire™

**OWNER'S GUIDE
GUIDE DE L'UTILISATEUR
GUIA DEL PROPIETARIO**



**READ AND KEEP THESE
IMPORTANT INSTRUCTIONS**

**LIRE ET CONSERVER CES
INSTRUCTIONS IMPORTANTES**

**LEA Y TENGA EN CUENTA ESTAS
INSTRUCCIONES IMPORTANTES**

Important Instructions

READ ALL INSTRUCTIONS BEFORE USING THIS HEATER

Please visually inspect all internal and external components before connecting to electric current. If any damage is found, DO NOT USE THIS UNIT and contact Vornado Air LLC at 1-800-234-0604.

WARNING! This is a heater – not a toy and not intended for children.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Do not use this product as a step stool.
- Do not operate Vornado® SoleAire™ on an elevated surface such as a shelf or desktop. Use only while placed on the floor.
- Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains away from SoleAire.
- Do not operate SoleAire with a damaged cord or plug or after the unit malfunctions or has been dropped or damaged in any manner. Return it to Vornado for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic areas and where it will not be tripped over.
- Always unplug heater when not in use. To disconnect SoleAire, set the POWER switch to OFF, then remove plug from outlet.
- To prevent damage to the unit, do not block air intake and clean the air intake regularly.
- Do not insert or allow foreign objects to enter any ventilation or exhaust openings as this may cause an electric shock or fire or damage to the heater.
- Do not place back of unit against a wall or obstruct air intake grill.
- Do not use on soft or uneven surfaces like a bed, couch, etc., where openings may become blocked.
- Operate this heater only in its upright position.
- Do not use SoleAire in areas where gasoline, paint or flammable liquids are used or stored.
- Use SoleAire only as described in this owner's guide. Any other use not recommended by Vornado may cause fire, electric shock or injury to persons.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If it still does not fit, contact a qualified electrician. If the plug does not fit fully in the outlet, reverse the plug. Do not attempt to defeat this safety feature.
- SoleAire is not intended for use in bathrooms, laundry areas and similar indoor damp locations. Never locate SoleAire where it may fall into a bathtub or other water container.
- Do not use with a power strip or an extension cord because it may overheat and cause a risk of fire.
- Do not operate this product with any electronic speed-control device on the same circuit.
- Do not use heater to dry human or animal hair/fur or articles of clothing.
- For indoor use only. Not for use in animal pens or outdoor buildings.

Maintaining Vornado® SoleAire™

SoleAire™ is designed to have no user serviceable parts inside. Do not disassemble SoleAire as this will void the warranty. If service is required contact the Vornado Customer Service Department. (See warranty)



- The motor is permanently lubricated and requires no oiling.
- Because SoleAire moves air, it will need regular cleaning of the surface and inlet grill. Be sure to unplug the unit prior to cleaning.
- Do not use solvents to clean SoleAire.
- During extended periods of non-heating use you may continue to use SoleAire as a footrest or as a foot fan, so regular cleaning of the surface is still suggested.

About your new Vornado® SoleAire™

Your new Vornado® SoleAire™ is an innovative product that solves a common yet widely ignored source of discomfort...cold feet. SoleAire is an ergonomic footrest that helps warm cold feet by allowing direct contact with heated air fan-forced through its surface. SoleAire also provides relaxing passive foot massage from surface bumps while promoting good seated posture at home or in the office.

Vornado SoleAire delivers a choice of 225 watts for fast warm-up or 150 watts for day-long personal comfort as heated air rises from under the desk to surround you in a blanket of warmth. The low wattage consumption is "office-friendly"...avoiding circuit overload typical with 1,000 or 1,500 watt heaters. Vornado SoleAire will give you lasting satisfaction and personal comfort.



SoleAire™ Features and Benefits

Fan-Forced Air

The large surface accommodates feet easily and disperses warm air across its entire surface...quickly warming cold feet.

Ergonomic Design

The design of SoleAire™ promotes good seated posture, with knees elevated above the hips to reduce stress on the lower back.

Massage Surface

The bumpy texture on the surface of SoleAire provides passive foot massage.

Automatic Shut-Off

Automatically shuts off after 4 hours of use. To reset, turn the unit off then back on.

Safe-to-Touch

SoleAire is designed to place feet directly on the surface. While warm enough to quickly warm cold feet, surfaces are not hot to the touch.

Over-Heat Protection

SoleAire incorporates an internal over-temperature thermal breaker with a fail-safe back-up fuse. If abnormally high operating temperature occurs, power to the heat element will cut off automatically.

Full-Function Foot-Operated Controls

Rocker switch controls are simple and easy to operate with feet or toes...no bending over to adjust heat settings or to turn SoleAire on and off. There is a fan only setting for summer use. The power switch lights up to indicate the unit is on.

Compact Size

Fits perfectly under the desk at work or in front of your favorite chair at home.

Quiet Operation & Solid Construction

SoleAire moves air so quietly you'll hardly know it's there. High-impact plastic construction means no parts to dent, come loose or rattle.

Heat Settings

225 watts on HIGH, 150 watts on LOW, and no heat in FAN ONLY setting.

Power Switch

Lights up to indicate the unit is on.

Non-Slip Feet

SoleAire stays where you put it.



Helpful Tips



Vornado® SoleAire™ is intended for floor use only. It is ideal for use in offices or at home in front of your favorite chair. SoleAire solves the discomfort of cold feet by gently surrounding feet and the lower body with just enough heat to keep you comfortable, without heating an entire room or using excessive amounts of electricity.

Controls are easy to operate with toes or feet...no bending over required to turn on, off or adjust the heater. The power switch will be lit when the unit is on. Heat mode settings are selected by pressing on either side of the Heat switch. "**HIGH**" heat to the left, "**FAN ONLY**" (no heat) in the middle and "**LOW**" heat to the right. In summer, or when feet are hot, the "**FAN ONLY**" mode will cool-down feet.

For fast warm-up or in extra cold rooms, set SoleAire on "**HIGH**" heat. The "**LOW**" heat setting may be appropriate for most conditions. Note: When you first take off your shoes, the air movement against damp feet might make your feet feel cool, allow time for your feet to dry and adjust to the heated air.

When the unit has been in use for 4 hours, it will automatically turn off. The illuminated power switch will remain on. To reset, turn the unit off, then back on. The unit will run for another 4 hours of use and shut off or you may turn the unit off at anytime. This feature conserves energy, saving you money. Always turn the unit off after using.

SoleAire has a contoured surface to allow a variety of foot positions. Experiment to find your favorite position for comfort. The bumpy surface provides a relaxing passive foot massage for tired feet. With shoes, the bumpy surface keeps the soles of shoes above the air outlet holes and allows heat to flow under feet. With high heels, it may be more comfortable to rest toes on the SoleAire and rest heels on the floor.

SoleAire can be used as a personal heater even when not resting feet on it. This appliance is intended as a personal heater, not as a room heater. Remember to turn off the heater after use to save electricity.

Upon initial use, product may emit a faint odor associated with many new products. Odor should dissipate with use.

Vornado Air LLC 1-Year Limited Warranty

Vornado Air LLC warrants to the original consumer or purchaser that the Vornado® SoleAire™, is free from any defects in material or workmanship for the length of term as described above. If any such defect is discovered within the warranty period, Vornado Air LLC, at its discretion, will repair or replace the unit.

This limited warranty covers parts failure or manufacturing flaw. It does not apply to defects resulting from abuse of the unit, modification, alteration, repair or service by anyone other than Vornado Air LLC, mishandling, improper maintenance, commercial use of the unit, damages which occur in shipment or are attributable to acts of God.

THIS WARRANTY IS THE ONLY ONE WE GIVE ON YOUR VORNADO SOLEAIRE. IT SETS FORTH ALL OUR RESPONSIBILITIES REGARDING YOUR VORNADO SOLEAIRE. THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED ABOVE. VORNADO AIR LLC SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THE WARRANTY. ANY IMPLIED WARRANTIES INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or a limitation on how long the implied warranties last; so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may have other rights that vary from state to state.

HOW TO OBTAIN RETURN AUTHORIZATION

For warranty or repair service, email consumerservice@vornado.com or call 1-800-234-0604 to obtain a Return Authorization (RA) form. Please have or include your SoleAire model number and serial number, as well as your name, address, city, state, ZIP code and phone number. After receiving the RA form in the mail, ship your SoleAire postage-paid with a copy of the original dated receipt of purchase along with a check or money order for \$20.00 (to cover return shipping and handling) to:

Vornado Air LLC
415 E. 13th Street
Andover, KS 67002

To assure proper handling, packages must be clearly marked with the RA number. Packages not clearly marked with the RA number may be refused at the receiving dock.

For your records: Staple or attach your original sales receipt to this owner's guide. Please also write your SoleAire serial and model numbers below (located on product specs decal).

Serial No. _____
Model No. _____

Please allow 1-2 weeks for the repair and return of your Vornado SoleAire after it has been received.

©2008 Vornado Air LLC, Andover, KS 67002

Vornado® and SoleAire™ are trademarks of Vornado Air LLC.

Specifications subject to change without notice.

U.S. Patent D-441,065

Designed and Engineered in the USA. Manufactured in China.

PRODUCT REGISTRATION AVAILABLE ONLINE AT www.vornado.com

Vornado Consumer Services

P 1-800-234-0604 **W** www.vornado.com **E** consumerservice@vornado.com