

Bass String Lengths

D'Addario

Short Scale = 32" Ball to Taper (or Silk)

Medium Scale = 34" Ball to Taper (or Silk)

Long Scale = 37.1" Ball to Taper (or Silk)

Super Long Scale = 38" Ball to Taper (or Silk)

Dean Markley

Long Scale = 37.25" Ball to Taper (or Silk)

DR Strings

Short Scale = 34" Ball to Taper (or Silk)

Long Scale = 38" Ball to Taper (or Silk)

Extra Long Scale - 40.7" Ball to Taper (or Silk)

Dunlop

Long Scale = 37.25" Ball to Taper

Elixir

Long Scale = 36.5" Ball to Taper

Extra Long Scale = 38" Ball to Taper

Ernie Ball

Long Scale = 37.25" Ball to Taper (or Silk)

Super Long Scale = 38.25" Ball to Taper

Fender Bass

Short Scale = 32" Ball to Taper

Medium Scale = 34" Ball to Taper

Long Scale = 36.5" Ball to Taper

Fodera

Long Scale = 37.5" Ball to Taper

Extra Long Scale = 39.25" Ball to Taper

GHS

Short Scale: 32" Ball to Taper (or Silk)

Medium Scale: 34" Ball to Taper (or Silk)

Long Scale: 36.5" Ball to Taper (or Silk)

Long Plus: 38" Ball to Taper (or Silk)

Ken Smith

Long Scale = 38" Ball to Silk

Extra Long Scale = 40" Ball to Silk

For some B strings there is a "Medium Scale" option = 36.5" Ball to Silk

La Bella

Short Scale = 32" Ball to Silk

Medium Scale = 34" Ball to Silk

Long Scale = 37" Ball to Silk

Extra Long Scale = 38" Ball to Silk

Hofner Beatle Bass = 34" Ball to Silk

Rotosound

Short Scale = 32" Ball to Silk

Medium Scale = 34" Ball to Silk

Long Scale = 37" Ball to Silk (or Taper)

Extra Long Scale = 39" Ball to Silk

SIT

Long Scale = 37.25" Ball to Taper

Extra Long Scale = 38" Ball to Taper

Thomastik-Infeld

Short Scale = 35.5" Ball to Silk

Long Scale = 37" Ball to Silk

Super Long Scale = 39.75" Ball to Silk