



*Quality Shuffleboards  
at an Unbeatable Price*

# User Manual

## COIN-OPERATED SCOREBOARD

### Instructions

1. Push the On - Off Button on, this will turn the red light on.
  - a. The Mode Button is to select the 15 - 21 - Timer - Horsecollar settings.
  - b. The Bottom Red Light is Horsecollar, the next up is 15 Points, the next is 21 Points & the top 1 is your Timer.
2. To select Coins per game
  - a. Press Up or Down to set your Coins "per game"
3. To set the Timer:
  - a. Press Mode Button
  - b. The top red light comes on
  - c. Press up or down button to set time. This will set "Minutes per game"
4. To set Horsecollar:
  - a. Bottom light will come on
  - b. Press up or down this will set "Coins per Player"

Note - The number 21 number has to be higher than the 15 points number.

"0" means the game or time is turned off.

**\*\*\*IMPORTANT\*\*\*** Be sure Red Light on Panel is turned "OFF" or Scoreboard will not work. If coins are inserted & 0 - 0 is displayed the panel will not turn on. In this case score a point, then turn on panel.