



INSTRUCTIONS AND PACKAGE CONTENTS ITEM 61708



PART	DESCRIPTION	QTY
A	*Plastic Brackets for 3" Center Pole (front piece and back piece)	4
B	*Plastic Brackets for 2.5" Center Pole (front piece and back piece)	4
C	Hardware (4 - M5*70 bolts/4 - M5 nuts)	8
D	Dimmer Switch Module	1

*NOTE: You will use Part B assembled inside of Part A for use on the 2.5" Pole.




Tools needed for assembly (NOT included): Philips Head Screwdriver

Assembly Time: 10 minutes


Step 1:

Place front piece of Plastic Bracket (A or A and B) on pole. Align holes in the top of the Dimmer Switch Module with the holes in the front piece of Plastic Bracket. Insert 2 - M5*70 bolts through holes. Then attach the back piece of the Plastic Bracket (A or A and B) onto the M5*70 bolt and secure to the pole by tightening 2 - M5 nuts onto the end of the M5*70 bolts. Repeat with the second set of Plastic Brackets (A or A and B.)



Step 2:

Once the Dimmer Switch Module has been secured to the pole, plug the cord from the Infrared Heater into the Dimmer Switch module. Then to use the Infrared Heater, plug the Dimmer Switch module cord into a wall outlet. This appliance must be used with an outlet that has been installed and grounded in accordance with local codes and ordinances. Make sure the appliance is connected to an outlet having the same configuration as shown in the figure below. DO NOT use an adapter with this product. Check with a licensed electrician if the grounding instructions are not understood completely or if the wall outlet does not match the plug shown below. **We recommend that you use a DEDICATED LINE for operation of this appliance as it will draw 1500 watts/13 amps during operation.**



Step 3:

To operate the Dimmer Switch Module, lift the transparent plastic cover to expose the knob. Make sure you begin with the knob in the "OFF" position. Then turn the knob clockwise to the "MIN" position. To increase the heat, continue to turn the knob clockwise toward the "MAX" position (**NOTE: MIN wattage is 200w and MAX is 1500w.**) From the "MAX" position, turn the knob counterclockwise towards "MIN" to decrease the wattage. Make sure to turn the knob to "OFF" and unplug the Dimmer Switch Module from the wall outlet when the heater is NOT in use.



Lift Transparent Cover

Make sure Dimmer Switch is turned to OFF before you plug into wall outlet.

To adjust heat, turn knob CLOCKWISE to MIN and then continue to turn CLOCKWISE to MAX to increase heat. To decrease heat, turn knob COUNTERCLOCKWISE toward MIN.

Make sure to turn Dimmer Switch to OFF before unplugging the Dimmer Switch from the wall outlet.

Distributed By:
Well Traveled Living
716 S 8th Street
Amelia Island, FL 32034
Toll Free: 866-WTL-SUPP
(866-985-7877)



Web: www.wtliving.com
Email: cservice@welltraveled.net

1 YEAR LIMITED WARRANTY – Customers in the Continental US

All components are warranted for a period of 1 year after date of purchase by the original owner against defects in materials and workmanship under normal use. This warranty does NOT cover normal wear and weathering, assembly and/or maintenance OR use in a commercial application if model is not designated as a commercial model. At Well Traveled Living's sole discretion, products under warranty will be repaired and/or replaced at no charge to the customer. Any returns sent back to Well Traveled Living must be sent via prepaid freight and in the original retail packaging.

For warranty service contact Well Traveled Living at the address, phone numbers or internet site and email listed in this owner's manual. Be sure to have your sales receipt, date of purchase and catalogue/model numbers available when calling. All warranty service will be coordinated by the Well Traveled Living's, Amelia Island, Florida service center.

This warranty is extended only to the original purchaser. Proof of purchase will be required before warranty service is rendered. The sales receipt is the only valid proof of purchase. This warranty only covers failures due to defects in materials or workmanship which occur during normal use. Failures and/or damage which result from accident, negligence, misuse, abuse, neglect, mishandling, alteration or modification, failure to maintain, improper assembly or maintenance, service by unauthorized agency or use of unauthorized components or damage that is attributable to acts of God are NOT covered.

*****THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED ABOVE*****

*****PURCHASER ASSUMES ALL RISKS IN THE ASSEMBLY AND OPERATION OF THIS UNIT*****

*****FAILURE TO FOLLOW WARNINGS AND OPERATIONAL INSTRUCTIONS CONTAINED IN THIS MANUAL CAN RESULT IN SEVERE PROPERTY DAMAGE AND/OR PERSONAL INJURY*****

IN NO EVENT WILL WELL TRAVELED LIVING, OR ITS DIRECTORS, OFFICERS OR AGENTS BE LIABLE TO THE PURCHASER OR ANY THIRD PARTY, WHETHER IN CONTRACT, IN TORT, OR ON ANY OTHER BASIS, FOR ANY INDIRECT, SPECIAL, PUNITIVE, EXEMPLARY, CONSEQUENTIAL, OR INCIDENTAL LOSS, COST, OR DAMAGE ARISING OUT OF OR IN CONNECTION WITH THE SALE, MAINTENANCE, USE, OR INABILITY TO USE THE PRODUCT, EVEN IF WELL TRAVELED LIVING OR ITS DIRECTORS, OFFICERS OR AGENTS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSSES, COSTS OR DAMAGES, OR IF SUCH LOSSES, COSTS, OR DAMAGES ARE FORESEEABLE. IN NO EVENT WILL WELL TRAVELED LIVING, OR ITS OFFICERS, DIRECTORS, OR AGENTS BE LIABLE FOR ANY DIRECT LOSSES, COSTS OR DAMAGES THAT EXCEED THE PURCHASE PRICE OF THE PRODUCT.

SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO THE PURCHASER.

This limited warranty gives you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction. The provisions of the United Nations Convention on Contracts for the Sales of Goods shall not apply to this limited warranty or the sale of products covered by this limited warranty.

*****IMPORTANT NOTICE*****

-Do **NOT** return to place of purchase-
For customer service and warranty issues
contact our Customer Service Center at:
(866)-985-7877 OR
Email: cservice@welltraveled.net
Customer Service Hours: Mon. – Fri. 9:00 a.m. – 6:00 p.m.
(EST)

Fire Sense®, Mojave Sun®, and Well Traveled Living® are registered trademarks of Well Traveled Imports, Inc®. All assembly instruction presentations are the property of Well Traveled Imports, Inc.® and are protected by U.S. copyrights and trademarks. All rights reserved.