Takagi Industrial Co. USA Inc.
Thermostat Extension Wire
Installation Manual

If the T-K2 is to be installed indoors in an area where the outdoor temperatures will drop below freezing, please extend the ambient temperature thermostat to the outdoors.

1. Open the front cover of the unit by removing the two screws on either side of the front of the unit at the top.



Connection Thermostat

2. Disconnect the black plastic thermostat from the fan by removing a single screw. Replace the screw after removing the thermostat.

3. Disconnect the wire connection mid way along the wire from the thermostat to the computer.

4. Locate thermostat in an outdoor area in which it will be able to properly measure the ambient temperature.

5. Connect the extension wire to the corresponding open ends of the wires leading from the connection to the computer, and from the connection to the thermostat.

6. Obscure extension wire as desired.