

Artesian Pre-Installation Assessment

Thank you for your interest in TouchAmerica's Artesian table. The following checklist will help ensure that the installation site for your new equipment is adequately prepared. It will also help you understand basic installation requirements, and will assist in ease of installation and optimal operation of your new equipment.

The Artesian can be ordered with or without optional, pipeless jet system. All Artesians come with built-in water faucet/filling valve. Having plumber install hot/cold water to the Artesian is recommended, however, manual filling is possible. Draining into a built-in floor drain is recommended. Specify at time of order if planning to manually drain into a bucket or tub, in which case the optional Manual Drain Kit will be necessary.

Connecting the Artesian:

- I have received and reviewed the specifications and requirements for the Artesian.
- I understand that I am responsible for complying with all local building codes that pertain to the installation of the Artesian table.
- To use the internal filling valve, the Artesian requires ½" dia. hot/cold water supply lines.
- Water supply lines are to be positioned on the floor, under the Artesian per specifications, or alternate water supply attachment must be established.
- To use the internal drain in the foot sink, the Artesian requires a 1½" diameter floor drain.
- The floor drain will need to be located under the Artesian, in the area designated on the installation drawing.
- If you do not have a floor drain available or if the Artesian is in a basement, please contact TouchAmerica for pump recommendations to remove wastewater, or order Manual Drain Kit to drain into a tub or bucket.
- The Artesian occupies a space 30" wide and 73" long. The treatment room needs to be large enough to accommodate the Artesian, and still have a minimum of 30" working room around the table.
- Artesian requires a 120VAC 15AMP electrical circuit. Electrical outlets supplying the Artesian should be GFI protected.

Shipping:

The Artesian table will arrive fully assembled, on a wood pallet, and packed in cardboard. The shipping crate measures 83" x 39" x 37." Shipping weight is 300 lbs. If TouchAmerica is arranging freight service for you, please let your TouchAmerica representative know at time of freight quote if you need Lift Gate, Inside Delivery and/or Call-Ahead for Delivery Appointment. You will need a Lift Gate on the truck to transfer freight to ground level, unless you have a loading dock. If you would like the driver to assist your staff in bringing the crate through the exterior doors, select Inside Delivery. Driver will usually call when he is on his way, if Inside Delivery has been specified. If you need more notice in order to be prepared for the delivery, select Call-Ahead for Delivery Appointment. If you would like the freight company to unpack the crate and bring the table into an interior room, with no assistance from your staff, ask for a White Glove quote; this delivery option is significantly more expensive.