


# ***Accurate***

***Partitions Corp***

---

## **INSTALLATION INSTRUCTIONS FOR** **POLYMER SOLID PLASTIC PARTITIONS**



# Accurate

Partitions Corp

## Table Of Contents

<u><b>Floor Anchored/Overhead Braced</b></u>	<u><b>Page</b></u>
Step 1,2,3.....	1
Step 4,5,6.....	2
Panel To Pilaster/Wall Two Ear Assembly.....	3
Panel To Pilaster/Wall One Ear Assembly.....	4
Pilaster/Wall One Ear Assembly.....	5
Pilaster/Panel Alcove Assembly.....	6
Door Hardware (Vault Hinge) Assembly.....	7 & 7A
Door Hardware (Integral Hinge) Assembly.....	8
Door Hardware (Piano Hinge) Assembly.....	9
Headrail Assembly.....	10
Urinal Screen Assembly.....	11

<u><b>Ceiling Anchored</b></u>	<u><b>Page</b></u>
Step 1,2,3.....	12
Step 4,5,6.....	13
Panel To Pilaster/Wall Two Ear Assembly.....	14
Panel To Pilaster/Wall One Ear Assembly.....	15
Pilaster/Wall One Ear Assembly.....	16
Pilaster/Panel Alcove Assembly.....	17

<u><b>Floor Anchored And Ceiling Anchored</b></u>	<u><b>Page</b></u>
Step 1,2,3.....	18
Step 4,5,6.....	19
Panel To Pilaster/Wall Two Ear Assembly.....	20
Panel To Pilaster/Wall One Ear Assembly.....	21
Pilaster/Wall One Ear Assembly.....	22
Pilaster/Panel Alcove Assembly.....	23

# **Accurate**

**Partitions Corp**

## Table Of Contents

<u>Full Height Aluminum Kits</u>	<u>Page</u>
Panel To Pilaster/Wall Two Ear Assembly.....	24
Panel To Pilaster/Wall One Ear Assembly.....	25
Pilaster/Wall One Ear Assembly.....	26
 <u>Product Information</u>	
Care And Maintenance Of Toilet Partitions.....	27

*The Components for this project have been custom fabricated. They are guaranteed with respect to manufacture and workmanship and were inspected at the factory.*

*Before beginning work, the units should be inspected. If damage occurred in transit, report immediately to the freight company or other agencies that may have caused the damage.*

# Accurate

Partitions Corp

## STEP 1


### LAYOUT

#### FLOOR ANCHORED/OVERHEAD BRACED

NOTE: FLOOR MUST BE CONCRETE

- Review the layout drawings and package lists that have accompanied this job.
- Before proceeding, confirm that backing of walls and floor is adequate to support secure mounting of the toilet compartment units.
- Establish and mark pilaster center line from back wall.
- Establish and mark panel center lines for wall brackets.
- Establish pilaster floor fastener locations from side wall according to shop drawings. (Note: Floor fasteners are located 1" from edge of pilaster.)
- Mark wall bracket holes using brackets as templates.

FIGURE 1




## STEP 2

### WALL BRACKETS AND FLOOR ANCHORS

- Drill holes for wall brackets and floor anchors of appropriate size for particular fastening devices supplied.
- Insert anchoring devices in walls and secure wall brackets.
- Insert anchoring devices in walls and secure wall brackets.
- Install wedge anchor, washer and nut into concrete floor and tighten.

FIGURE 2




## STEP 3

### POSITION PANEL

- Place panel on a support, 14" above the floor.
- Set it into wall brackets, but do not fasten panel at this time.

FIGURE 3




# Accurate Partitions Corp

## STEP 4

### PILASTER PREPARATION

- A. Align brackets in position on rear of pilasters. Refer to layout drawings.
- B. Fasten brackets to pilaster with sheet metal screws.
- C. Pilasters at wall do not require U-brackets, but should be prepared for wall (and floor fastening) as required by compartment layout. If floor fastening is omitted, three wall brackets should be used.




**FIGURE 4**

## STEP 5

### INSTALL PILASTERS

- A. Slide shoe carefully over mounting end of pilaster and leave approximately 5" above end.
- B. Thread support nuts and mounting washers over wedge anchor to support pilaster mounting bar.
- C. Position pilaster and mounting bar on threaded anchor and attach lightly with square flat washer, lockwasher and locking nut.




**FIGURE 5**

## STEP 6

### SECURING PILASTER/PANEL

- A. Level each pilaster by adjusting both support nuts to desired position.
- B. Plumb each pilaster and fasten the pilaster to panel using through bolts.
- C. Establish door openings by setting pilaster mounting bar to desired position on anchor.
- D. Tighten locking nuts on top of pilaster mounting bar.
- E. Slide shoe down to floor level engaging shoe clips, for plastic shoes, if stainless steel shoes, use screw.
- F. Fasten panel to wall brackets using through bolts.
- G. Remove panel support device.



**FIGURE 6**

# Accurate

## Partitions Corp

### FLOOR ANCHORED/OVERHEAD BRACED

#### PANEL TO PILASTER/WALL

#### TWO EAR ASSEMBLY







#### POLYMER

Pilasters must be both plumb and level. To assist in leveling, headrail may be lightly positioned across adjacent pilasters (do not fasten at this time).

A. Plumb panel and fasten panel to two ear bracket at wall with through bolts.

B. Plumb pilaster and fasten pilaster to panel using through bolts two ear brackets.

Panel Hardware Kit (P/N 8445020) Includes:  
ALUMINUM

PART ID.	DESCRIPTION	QTY
1	 5441750 Two Ear Alum. Bracket	(6)
2	 3260600 Theft Resistant S/S #10-24 x 1" Step Bolts	(6)
3	 3260690 Theft Resistant S/S #10-24 x 5/8" Barrel Nut	(6)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(6)
5	 3080000 Plastic Shields	(6)
6	 3264320 Theft Resistant S/S #14 x 5/8" S.M.S	(6)






FIGURE A



DRILL 1/4" DIA. HOLE(TYP)

14"  
A.F.F.

PANEL






FIGURE B



PILASTER




FIGURE A

Panel to wall




FIGURE B

Panel to pilaster

# Accurate







## Partitions Corp


### FLOOR ANCHORED/OVERHEAD BRACED PANEL TO PILASTER/WALL ONE EAR ASSEMBLY POLYMER

Pilasters must be both plumb and level. To assist in leveling, headrail may be lightly positioned across adjacent pilasters (do not fasten at this time).

- Plumb panel and fasten panel to one ear bracket at wall with through bolts.
- Plumb pilaster and fasten pilaster to panel using through bolts two ear brackets.

Panel Hardware Kit (P/N 8445010) Includes:  
ALUMINUM


PART ID.	DESCRIPTION	QTY
1	 2441760 One Ear Alum. Bracket	(6)
2	 3260600 Theft Resistant S/S #10-24 x 1" Step Bolts	(6)
3	 3260690 Theft Resistant S/S #10-24 x 5/8" Barrel Nut	(6)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(6)
5	 3080000 Plastic Shields	(6)
6	 3264320 Theft Resistant S/S #14 x 5/8" S.M.S	(6)



BACK WALL



FIGURE A



DRILL 1/4" DIA. HOLE(TYP)

14"  
A.F.F.

PANEL




FIGURE B



PILASTER




FIGURE A

Panel to wall




FIGURE B

Panel to pilaster

# Accurate







## Partitions Corp



### FLOOR ANCHORED/OVERHEAD BRACED PILASTER/WALL ASSEMBLY POLYMER

Pilasters must be both plumb and level. To assist in leveling, headrail may be lightly positioned across adjacent pilasters (do not fasten at this time).

- A. Establish door openings by adjusting pilaster mounting bar & nuts to desired position and tightening.
- B. Plumb pilaster and fasten pilaster to wall brackets using through bolts.

Pilaster/Wall Hardware Kit (P/N 8445210) Includes:  
ALUMINUM

PART ID.	DESCRIPTION	QTY
1	 2441760 One Ear Wall Bracket	(3)
2	 3260600 Theft Resistant S/S Step Bolts #10x 24 x1" Long	(3)
3	 3260690 Theft Resistant S/S Barrel Nut	(2)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(6)
5	 308000 Plastic Shelds	(6)
6	 3264320 Theft Resistant S/S #14 x 3/4" S.M.S	(6)













# Accurate


## Partitions Corp

### FLOOR ANCHORED/ OVERHEAD BRACED PILASTER/PANEL ALCOVE ASSEMBLY POLYMER

Optional #8447020 2-ear Alcove Kit.  
Not recommended by Accurate Partitions Corp.

Panel Hardware Kit (P/N 8447010) includes:  
ALUMINUM

PART ID.	DESCRIPTION	QTY
1	 2441760 One Ear Alum. Bracket	(6)
2	 3260600 Theft Resistant S/S #10-24 x 1" Step Bolts	(12)
3	 3260690 Theft Resistant S/S #10-24 x 5/8" Barrel Nut	(12)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(14)
5	 308000 Plastic Shields	(14)
6	 3264320 Theft Resistant S/S #14 x 3/4"	(3)
7	 6265150 Alcove Clip S/S	(6)
8	 2521980 Headrail Bracket	(1)



**NOTE:**  
Replace #3260450 Theft Resistant S/S #14 x 2 1/2"  
With #3264320 Theft resistant S/S #14 X 3/4"  
To Fasten Pilaster To Panel.

# Accurate

## Partitions Corp

### DOOR HARDWARE

#### ASSEMBLY-VAULT HINGE

#### POLYMER

Install slide latch on door opposite the hinge side of door. All slide latches should be mounted at midpoint of the door, 27 1/2" inches up from the bottom of the door.

#### INSWING DOOR


Mount the slide latch on to the door with four (4) 10-24 X 1 inch step bolts and four (4) 10-24 X 1/2 inch barrel nuts. Install keeper and bumper on pilaster. Be sure that the keeper and bumper is set so that the slide bar of the slide latch engages the top notch of the keeper. Install keeper/bumper with two (2) 10-24 x 1-1/4 inch step bolts and two (2) 10-24 X 1/2 inch barrel nuts.























#### OUTSWING DOOR

Mount the slide latch, and bumper on to the door. Slide latch on inside face, bumper on outside face. Use two (2) 10-24 x 1-1/4 inch step bolts at the front holes and (2) 10-24 x 1 inch step bolts at the back holes, use four (4) (2) 10-24 x 3/8 inch barrel nuts also for mounting. Install keeper on pilaster. Be sure that the keeper is set so that the slide latch bar is only 1/4 inch (.250) below the top edge of the keeper. Install keeper with (2) 10-24 x 1-1/4 inch step bolts and two (2) 10-24 x 3/8 inch barrel nuts.

#### EMERGENCY ACCESS

Lift door causing latch bolt to clear keeper and open.



Outswing Door Hardware Kit (P/N 8571008) includes: Brushed Finish			
PART ID.	DESCRIPTION		QTY
1		2562820 Vault Hinge Top Pilaster Side	(1)
2		2562830 Vault Hinge Top Door Side	(1)
3		2562850 Vault Hinge Bottom Door Side	(1)
4		2562840 Vault Hinge Bottom Pilaster Side	(1)
5		3081980 Spacer hinge top/ Bottom Door Side (For Phenolic Use Only)	(1)
6		3081970 Spacer hinge Bottom Door Side (For Phenolic Use Only)	(1)
7		3081990 Spacer hinge Pilaster Side (For Phenolic Use Only)	(2)
8		2562870 Cam Adjusting Bottom Hinge	(1)
9		8082790 Bushing Nylon Top Hinge	(1)
10		2562860 Nut Adjusting Bottom Hinge	(1)
11		xxxxxxx Hinge Washer Internal	(1)
12		2563900 Side Latch Brushed Finish	(1)
13		2562740 Outswing Slide Latch Keeper	(1)
14		2511700 Pull Handle	(1)
15		3260700 Tamper Resistant S/S Step Bolts #10-24 x 1-1/4"	(2)
16		2561600 Bumper And Coathook	(1)
17		3260600 Tamper Resistant S/S Step Bolts #10-24 x 1"	(8)
18		3260750 Tamper Resistant S/S Step Bolts #10-24 x 3/4" (For Phenolic Use Only)	(1)
19		3260590 Tamper Resistant S/S Barrel Nut #10-24 x 1/2"	(8)
20		3262130 Tamper Resistant S/S #10 x 5/8"	(4)
21		3260690 Tamper Resistant S/S Barrel Nut #10-24 x 5/8"	(1)
22		2511710 Bumper	(1)

# Accurate Partitions Corp

## DOOR HARDWARE ASSEMBLY-VAULT HINGE POLYMER

Install slide latch on door opposite the hinge side of door. All slide latches should be mounted at midpoint of the door, 27 1/2" inches up from the bottom of the door.

### INSWING DOOR



















Mount the slide latch on to the door with four (4) 10-24 X 1 inch step bolts and four (4) 10-24 X 1/2 inch barrel nuts. Install keeper and bumper on pilaster. Be sure that the keeper and bumper is set so that the slide bar of the slide latch engages the top notch of the keeper. Install keeper/bumper with two (2) 10-24 x 1-1/4 inch step bolts and two (2) 10-24 X 1/2 inch barrel nuts.


### OUTSWING DOOR

Mount the slide latch, and bumper on to the door. Slide latch on inside face, bumper on outside face. Use two (2) 10-24 x 1-1/4 inch step bolts at the front holes and (2) 10-24 x 1 inch step bolts at the back holes, use four (4) (2) 10-24 x 3/8 inch barrel nuts also for mounting. Install keeper on pilaster. Be sure that the keeper is set so that the slide latch bar is only 1/4 inch (.250) below the top edge of the keeper. Install keeper with (2) 10-24 x 1-1/4 inch step bolts and two (2) 10-24 x 3/8 inch barrel nuts.

### EMERGENCY ACCESS

Lift door causing latch bolt to clear keeper and open.


Inswing Door Hardware Kit (P/N 8571007) Includes: Brushed Finish			
PART ID.	DESCRIPTION		QTY
1		2562820 Vault Hinge Top Pilaster Side	(1)
2		2562830 Vault Hinge Top Door Side	(1)
3		2562850 Vault Hinge Bottom Door Side	(1)
4		2562840 Vault Hinge Bottom Pilaster Side	(1)
5		3081980 Spacer hinge top/ Bottom Door Side (For Phenolic Use Only)	(1)
6		3081970 Spacer hinge Bottom Door Side (For Phenolic Use Only)	(1)
7		3081990 Spacer hinge Pilaster Side (For Phenolic Use Only)	(2)
8		2562870 Cam Adjusting Bottom Hinge	(1)
9		8082790 Bushing Nylon Top Hinge	(1)
10		2562860 Nut Adjusting Bottom Hinge	(1)
11		xxxxxxx Hinge Washer Internal	(1)
12		2563900 Slide Latch Brushed Finish	(1)
13		2562840 Inswing Keeper Brushed	(1)
14		3260590 Tamper Resistant S/S Barrel Nut #10-24 x 1/2"	(10)
15		2561600 Bumper And Coathook	(1)
16		3260690 Tamper Resistant S/S Barrel Nut #10-24 x 5/8"	(1)
17		3260600 Tamper Resistant S/S Step Bolts #10-24 x 1"	(11)
18		3262130 Tamper Resistant S/S #10 x 5/8"	(2)



# Accurate Partitions Corp

## DOOR HARDWARE ASSEMBLY-INTEGRAL HINGE POLYMER

- A. Insert bottom intergral hinge cam side into door with high/low points parallel with door. See figure 1. Pin unit to door by drilling #25 (.1495) dia. hole a minimum of 1.75" deep through edge of door and hinge as noted on dwg. Lock edge of door and hinge lock unit into place with #10-24 cap point set screw 1" long. See figure 2.
- B. Insert bottom intergral hinge pin side into pilaster. See figure 3. Set door over bottom hinge. Hold door at an in tilt. Insert top integral hinge into hole at top of pilaster. See figure 4. Align door and let top pin fall into hole at top of door. See figure 5. Door is hung.
- C. Set door position. Closed for outswing door, open for inswing door. When door position is set drill #25 (.1495) dia. hole a minimum of 1.75" deep through the pilaster edge and hinge at bottom. Lock hinge into place with #10-24 cap point set screw 1" long. See figure 6.
- D. Drill #25 (.1495) dia. hole a minimum of 1.75" deep through both top hinge and door. Lock top pin into place using #10-24 cap point set screw 1" long. See figure 7.




### Inswing Door Hardware Kit (P/N 8981000) Includes:

PART ID.	DESCRIPTION	QTY
1	6980100 Top Integral Hinge Pin Nylon	(1)
2	6980200 Bottom Integral Hinge Cam Side Nylon	(1)
3	6980210 Bottom Integral Hinge Pin Nylon With 3/16" pin	(1)
4	2563890 Side Latch Brushed Finish	(1)
5	2562310 Keeper Brushed Finish	(1)
6	2562300 Door Stop Brushed Finish	(1)
7	2561600 Bumper And Coathook	(1)
8	3260600 Tamper Resistant S/S Step Bolts #10-24 x 1"	(6)
9	3260690 Tamper Resistant S/S Barrel Nut #10 x 5/8"	(6)
10	3262130 Tamper Resistant S/S #10 x 5/8"	(2)
11	3268151 P/H screw #10-24 x 1" Cap Point Set Screw	(4)
12	3082960 Spacer Door Stop	(1)

### Outswing Door Hardware Kit (P/N 8981010) Includes:

PART ID.	DESCRIPTION	QTY
1	2511700 Pull Handle	(1)
2	2511710 Bumper	(1)
3	3260700 Tamper Resistant S/S Step Bolts #10-24x1-1/4"	(4)
10	3262130 Tamper Resistant S/S #10 x 5/8"	(2)



# Accurate

## Partitions Corp

### DOOR HARDWARE ASSEMBLY-PIANO HINGE POLYMER


Door Hardware Kit (P/N 5261850) Includes:  
Brushed Finish

PART ID.	DESCRIPTION	QTY
1	5261850 S/S Spring Loaded Piano Hinge	(1)
2	8565700 Throw Latch	(1)
3	2562310 Keeper Brushed Finish	(1)
4	3082960 Spacer Door Stop	(1)
5	2562300 Door Stop Brushed Finish	(1)
6	2511600 Bumper And Coathook	(1)
7	3280700 Theft Resistant S/S Step Bolts #10-24 x 1-1/4 "	(2)
8	3280750 Theft Resistant S/S Step Bolts #10-24 x 3/4 "	(16)
9	3260690 Theft Resistant S/S Barrel Nut #10-24 x 5/8"	(18)
10	3912130 Theft Resistant S/S #10 x 5/8	(2)

#### NOTE

- OUTSWING DOOR HINGE FASTENED TO OUTSIDE FACE
- INSWING DOOR HINGE FASTENED TO INSIDE FACE


DRILL 1/4" DIA. HOLES (TYP.)








# Accurate


Partitions Corp

## HEADRAIL ASSEMBLY POLYMER



Headrail Hardware Kit (P/N 8448100) Includes:

PART ID.	DESCRIPTION	QTY
1	 2521980 Headrail Satin "F" Zamac Bracket	(2)
2	 2522200 Headrail Cap Satin Zamac	(1)
3	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(2)
4	 3080000 Plastic Shield 14/16 x 1-1/2"	(2)
5	 3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(4)








# Accurate

## Partitions Corp



### URINAL SCREEN FULL HEIGHT ASSEMBLY POLYMER

- Before proceeding, confirm that backing of wall is adequate to support and secure mounting of urinal screens.
- Insert anchoring devices in walls and secure wall brackets.
- Place urinal screen on a support, 14" above the floor.
- Set it into wall bracket and fasten urinal screen with through bolts at this time.

Urinal Screen Hardware Kit (P/N 8449000) Includes: ALUMINUM FULL HEIGHT			
PART ID.		DESCRIPTION	QTY
1		5449000 38" Long Two Ear Wall U/S Bracket	(1)
2		3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(8)
3		3080000 Plastic Shields	(8)
4		3260600 Theft Resistant S/S Step Bolts 1" Long	(4)
5		3260690 Theft Resistant S/S Barrel Nut	(4)

**NOTE:**

Optional Plastic full height(P/N 8989000-XXXX). "XXXX" Used To Designate Color.



**FIGURE A**

# Accurate


Partitions Corp

## STEP 1 LAYOUT CEILING ANCHORED

FIGURE 1

### STRUCTURAL SUPPORT BY OTHERS


- Review the layout drawings and package lists that have accompanied this job.
- Before proceeding, confirm that backing of wall and ceiling is adequate to support secure mounting of toilet compartment units.
- Confirm correct location and condition of threaded ceiling rods. These should project 2" to 2-1/2" below finished ceiling.
- Establish and mark pilaster and panel center lines in relation to ceiling rod locations and drawings.
- Mark wall bracket holes using brackets as templates.



## STEP 2 WALL BRACKETS AND CEILING ANCHORS

FIGURE 2


- Drill holes for wall brackets of appropriate size for particular fastening devices supplied.
- Insert anchoring devices in walls and secure wall brackets.
- Pilaster at wall should be prepared for wall and ceiling fastening as required by compartment layout.



## STEP 3 POSITION PANEL

FIGURE 3

- Place panel on a support, 14" above the floor.
- Set it into wall brackets, but do not fasten panel at this time.





## STEP 4

### PILASTER PREPARATION

- Align brackets in position on rear of pilasters. Refer to layout drawings.
- Fasten brackets to pilaster with sheet metal screws.
- Pilasters at wall do not require brackets, but should be prepared for wall and ceiling fastening as required by compartment layout.




FIGURE 4

## STEP 5

### INSTALL PILASTERS

- Slide shoe carefully over mounting end of pilaster and leave approximately 5" above end.
- Thread support nuts and mounting washers over stud to support pilaster mounting bar.
- Position pilaster and mounting bar on threaded anchor and attach lightly with shoe clip. If plastic shoe use square flat washer, lockwasher and locking nut. If stainless shoe no clip required.




FIGURE 5

## STEP 6

### SECURING PILASTER/PANEL

- Level each pilaster by adjusting both support nuts to desired position.
- Plumb each pilaster and fasten the pilaster to panel using through bolts.
- Establish door openings by setting pilaster mounting bar to desired position on anchor.
- Tighten locking nuts on top of pilaster mounting bar.
- Slide shoe up to ceiling level. If plastic shoe, engage shoe clips. If stainless shoes secure with screws.
- Fasten panel to wall brackets using through bolts.
- Remove panel support device.




FIGURE 6

# Accurate








## Partitions Corp

### CEILING HUNG PANEL TO PILASTER/WALL TWO EAR ASSEMBLY POLYMER


Pilasters must be both plumb and level.

- A. Plumb pilaster and fasten pilaster to panel using through bolts.
- B. Plumb panel and fasten panel to 2-Ear bracket at wall with through bolts and barrel nuts or sheet metal screws.

Panel Hardware Kit (P/N 8466020) Includes:  
ALUMINUM FULL HEIGHT

PART ID.	DESCRIPTION	QTY
1	 5441750 Two Ear Bracket	(1)
2	 5449540 "U" Bracket	(1)
3	 3260600 Theft Resistant S/S Step Bolts 1" Long	(12)
4	 3260690 Theft Resistant S/S Barrel Nut	(12)
5	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(12)
6	 3080000 Plastic Shields	(12)
7	 3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(12)

OPTIONAL:  
(P/N 8986020-XXXX) PLASTIC FULL HEIGHT BRACKET. "XXXX" Used To Designate Color.



# Accurate

## Partitions Corp

### CEILING HUNG

### PANEL TO PILASTER/WALL








### ONE EAR ASSEMBLY

### POLYMER

Pilasters must be both plumb and level.


- A. Plumb pilaster and fasten pilaster to panel using through bolts.
- B. Plumb panel and fasten panel to 1-Ear bracket at wall with through bolts and barrel nuts or sheet metal screws.

Panel Hardware Kit (P/N 8466010) Includes:  
ALUMINUM FULL HEIGHT

PART ID.	DESCRIPTION	QTY
1	 5442760 One Ear Bracket	(1)
2	 5449540 "U" Bracket	(1)
3	 3260600 Theft Resistant S/S Step Bolts 1" Long	(12)
4	 3260690 Theft Resistant S/S Barrel Nut	(12)
5	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(12)
6	 3080000 Plastic Shields	(12)
7	 3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(12)

#### OPTIONAL:

(P/N 8986010-XXXX) PLASTIC FULL HEIGHT BRACKET. "XXXX" Used To Designate Color.



# Accurate






## Partitions Corp

### CEILING HUNG PILASTER/WALL ASSEMBLY POLYMER

Pilasters must be both plumb and level.


- A. Plumb pilaster and fasten pilaster to wall using through bolts or sheet metal screws.
- B. Establish bottom door openings by adjusting pilaster mounting bar nuts to desired position and tightening screws.

Pilaster/Wall Hardware Kit (P/N 8466210) Includes:  
ALUMINUM FULL HEIGHT

PART ID.	DESCRIPTION	QTY
1	 5442760 One Ear Wall Bracket	(1)
2	 3260600 Theft Resistant S/S Step Bolts 1" Long	(6)
3	 32610690 Theft Resistant S/S Barrel Nut	(6)
4	 32610450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(12)
5	 3080000 Plastic Shields	(12)

#### NOTE:

For Pilaster/Wall Hardware Kit (P/N 8986210-XXXX) PLASTIC FULL HEIGHT.  
"XXXX" Used To Designate Color.



# Accurate








## Partitions Corp

### CEILING HUNG PILASTER/PANEL ALCOVE ASSEMBLY POLYMER

Pilasters must be both plumb and level.

- A. Plumb pilaster and fasten pilaster to panel using through bolts.
- B. Plumb panel and fasten panel to 1-Ear bracket at wall with through bolts and barrel nuts or sheet metal screws.








Panel Hardware Kit (P/N 8466010) Includes:  
ALUMINUM FULL HEIGHT

PART ID.	DESCRIPTION	QTY
1	 5442760 One Ear Bracket	(1)
2	 5449540 "U" Bracket	(1)
3	 3260600 Theft Resistant S/S Step Bolts 1" Long	(12)
4	 3260690 Theft Resistant S/S Barrel Nut	(12)
5	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(12)
6	 3080000 Plastic Shields	(12)
7	 3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(12)


OPTIONAL:  
(P/N 8986010-XXXX) PLASTIC FULL HEIGHT BRACKET. "XXXX" Used To Designate Color.

OR

Panel Hardware Kit (P/N 8466020) Includes:  
ALUMINUM FULL HEIGHT

PART ID.	DESCRIPTION	QTY
1	 5441750 Two Ear Bracket	(1)
2	 5449540 "U" Bracket	(1)
3	 3260600 Theft Resistant S/S Step Bolts 1" Long	(12)
4	 3260690 Theft Resistant S/S Barrel Nut	(12)
5	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(12)
6	 3080000 Plastic Shields	(12)
7	 3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(12)

OPTIONAL:  
(P/N 8986020-XXXX) PLASTIC FULL HEIGHT BRACKET. "XXXX" Used To Designate Color.



# Accurate

## Partitions Corp

### STEP 1


#### LAYOUT

#### FLOOR ANCHORED/CEILING ANCHORED

STRUCTURAL SUPPORT BY OTHERS  
FLOOR MUST BE CONCRETE

- Review the layout drawings and package lists that have accompanied this job.
- Before proceeding, confirm that backing of wall and ceiling support is adequate to secure mounting of toilet compartment units.
- Establish and mark pilaster center line from back wall.
- Establish and mark panel center lines for wall brackets.
- Establish pilaster floor and ceiling fastener locations from side wall according to shop drawings. (Note: Fasteners are located 1" from edge of pilaster).
- Confirm correct location and condition of threaded ceiling rods. These should project 2" to 2-1/2" below finished ceiling. Establish pilaster floor fastener location. Refer to layout dwgs.
- Mark wall bracket holes using brackets as templates.

FIGURE 1




### STEP 2

#### WALL BRACKETS AND FLOOR/CEILING FASTENERS

- Drill holes for wall brackets and floor anchors of appropriate size for particular fastening devices supplied.
- Insert wedge anchor in concrete floor and secure wall brackets.
- Insert wedge anchor into concrete floor and tighten.

FIGURE 2




### STEP 3

#### POSITION PANEL

- Place panel on a support, 14" above the floor.
- Set it into wall brackets, but do not fasten panel at this time.

FIGURE 3



# Accurate

## Partitions Corp

### STEP 4 PILASTER PREPARATION

- Align brackets in position on rear of pilasters. Refer to layout drawings.
- Fasten brackets to pilaster with sheet metal screws.
- Pilasters at wall do not require brackets, but should be prepared for wall floor and ceiling as required by compartment layout.




FIGURE 4

### STEP 5 INSTALL PILASTERS

- Slide shoes carefully over ends of pilaster and leave approximately 5" above end or below mounting.

- Position pilaster and mounting bar on threaded anchor and attach lightly with shoe clip, square flat washer, lockwasher and locking nut. If stainless steel shoes, no clip needed.





FIGURE 5

### STEP 6 SECURING PILASTER/PANEL

- Level each pilaster by adjusting both support nuts to desired position.
- Plumb each pilaster and fasten the pilaster to panel using through bolts.
- Establish door openings by setting pilaster mounting bar to desired position on stud.
- Tighten locking nuts on top of pilaster mounting bar.
- Slide shoe up to ceiling level, and down to floor firmly engaging shoe clips. If stainless steel, use screws.
- Fasten panel to wall brackets using through bolts.
- Remove panel support device.




FIGURE 6







# Accurate




## Partitions Corp

### FLOOR ANCHORED/CEILING ANCHORED PANEL TO PILASTER/WALL TWO EAR ASSEMBLY POLYMER

- A. Plumb pilaster and fasten pilaster to panel using through bolts.
- B. Plumb panel and fasten panel to two ear bracket at wall with through bolts.

Panel Hardware Kit (P/N 8445020) Includes:  
ALUMINUM

PART ID.	DESCRIPTION	QTY
1	 5441750 Two Ear Alum. Bracket	(6)
2	 3260600 Theft Resistant S/S #10-24 x 1" Step Bolts	(6)
3	 3260690 Theft Resistant S/S #10-24 x 5/8" Barrel Nut	(6)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S.	(6)
5	 3080000 Plastic Shields	(6)
6	 3264320 Theft Resistant S/S #14 x 5/8" S.M.S.	(6)



DRILL 1/4" DIA. HOLE(TYP)

14" A.F.F.

PANEL

FIGURE B



PILASTER




FIGURE A

Panel to wall




FIGURE B

Panel to pilaster









# Accurate

## Partitions Corp

### FLOOR ANCHORED/CEILING ANCHORED PANEL TO PILASTER/WALL ONE EAR ASSEMBLY POLYMER

- A. Plumb pilaster and fasten pilaster to panel using through bolts.
- B. Plumb panel and fasten panel to one-ear bracket at wall with through bolts.

Panel Hardware Kit (P/N 8445010) Includes:  
ALUMINUM

PART ID.	DESCRIPTION	QTY
1	 5441760 One Ear Alum. Bracket	(6)
2	 3260600 Theft Resistant S/S #10-24 x 1" Step Bolts	(6)
3	 3260690 Theft Resistant S/S #10-24 x 5/8" Barrel Nut	(6)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(6)
5	 3080000 Plastic Shields	(6)
6	 3264320 Theft Resistant S/S #14 x 5/8" S.M.S	(6)



BACK WALL





FIGURE A



HOLE LOCATION TO  
SUIT INSTALLATION

DRILL 1/4" DIA. HOLE(TYP)

14"  
A.F.F.

PANEL





FIGURE B



PILASTER




FIGURE A

Panel to wall




FIGURE B

Panel to pilaster







# Accurate



## Partitions Corp

### FLOOR ANCHORED/CEILING ANCHORED PILASTER/WALL ASSEMBLY POLYMER

Plumb pilaster and fasten pilaster to wall brackets using through bolts.

Pilaster/Wall Hardware Kit (P/N 8445210) Includes:  
ALUMINUM

PART ID.	DESCRIPTION	QTY
1	 5441760 One Ear Wall Bracket	(3)
2	 3260600 Theft Resistant S/S Step Bolts 1" Long	(3)
3	 3260690 Theft Resistant S/S Barrel Nut	(3)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(6)
5	 3080000 Plastic Shields	(6)
6	 3264320 Theft Resistant S/S #14 x 3/4" S.M.S	(6)



**FIGURE A**  
Pilaster to wall








# Accurate




## Partitions Corp

### FLOOR ANCHORED/CEILING ANCHORED PILASTER/PANEL ALCOVE ASSEMBLY POLYMER

Optional #8447020 2-Ear alcove kit.

Panel Hardware Kit (P/N 8447010) Includes:  
ALUMINUM

PART ID.	DESCRIPTION	QTY
1	 5441760 One Ear Alum. Bracket	(6)
2	 3260600 Theft Resistant S/S #10-24 x 1" Step Bolts	(12)
3	 3260690 Theft Resistant S/S #10-24 x 5/8" Barrel Nut	(12)
4	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(14)
5	 3080000 Plastic Shields	(14)
6	 3264320 Theft Resistant S/S #14 x 3/4"	(3)
7	 6265150 Alcove Clip S/S	(6)



#### NOTE:

Replace #3260450 Theft Resistant S/S #14 x 2 1/2"  
With #3264320 Theft resistant S/S #14 X 3/4"  
To Fasten Pilaster To Panel.








# Accurate

## Partitions Corp

### FLOOR ANCHORED/CEILING ANCHORED PANEL TO PILASTER/WALL TWO EAR ASSEMBLY POLYMER


Optional #8466010 1-Ear kit.

Panel Hardware Kit (P/N 8466020) Includes:  
ALUMINUM FULL HEIGHT

PART ID.	DESCRIPTION	QTY
1	 5442750 Two Ear Bracket	(1)
2	 5449540 "U" Bracket	(1)
3	 3260600 Theft Resistant S/S Step Bolts 1" Long	(12)
4	 3260690 Theft Resistant S/S Barrel Nut	(12)
5	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(12)
6	 3080000 Plastic Shields	(12)
7	 3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(12)

#### NOTE:

For Pilaster/Wall Hardware Kit (P/N 8986020-XXXX) PLASTIC FULL HEIGHT  
"XXXX" Used To Designate Color.










# Accurate

## Partitions Corp

### FLOOR ANCHORED/CEILING ANCHORED PANEL TO PILASTER/WALL TWO EAR ASSEMBLY POLYMER


Optional #8466010 1-Ear alcove kit.

Panel Hardware Kit (P/N 8466010) Includes:  
ALUMINUM FULL HEIGHT

PART ID.	DESCRIPTION	QTY
1	 5442750 One Ear Bracket	(1)
2	 5449540 "U" Bracket	(1)
3	 3260600 Theft Resistant S/S Step Bolts 1" Long	(12)
4	 3260690 Theft Resistant S/S Barrel Nut	(12)
5	 3260450 Theft Resistant S/S #14 x 2 1/2" S.M.S	(12)
6	 3080000 Plastic Shields	(12)
7	 3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(12)

#### NOTE:

For Pilaster/Wall Hardware Kit (P/N 8986010-XXXX) PLASTIC FULL HEIGHT  
"XXXX" Used To Designate Color.









# Accurate

## Partitions Corp


### FLOOR ANCHORED/CEILING ANCHORED PILASTER/WALL ASSEMBLY POLYMER

Pilaster/Wall Hardware Kit (P/N 8466210) Includes:  
ALUMINUM FULL HEIGHT

PART ID.		DESCRIPTION	QTY
1		5441840 One Ear Wall Bracket	(1)
2		3260700 Theft Resistant S/S Step Bolts 1 1/4" Long	(6)
3		3260690 Theft Resistant S/S Barrel Nut	(6)
4		3910450 TheftResistant S/S #14 x 2 1/2" S.M.S	(12)
5		3080000 Plastic Shields	(12)
6		3264120 Theft Resistant S/S #14 x 5/8" S.M.S	(12)

#### NOTE:

For Pilaster/Wall Hardware Kit (P/N 8986210-XXXX) PLASTIC FULL HEIGHT  
"XXXX" Used To Designate Color.



## **CARE AND MAINTENANCE OF TOILET PARTITIONS**

In order to provide toilet partitions with the care and maintenance, the following instructions must be followed.

A. All surfaces must be kept clean with water and a mild soap solution only.

B. In order to provide toilet partitions with the proper care and maintenance, the above instructions must be followed.

## **WARNING**

Under no circumstances should these components be subjected to:

- \*Abrasives powders or pads
- \*Water closet cleaners
- \*Ceramic tile cleaners
- \*Solutions containing more than 1 % by volume of ammonia
- \*Solutions containing acids or lye
- \*Solutions containing enzymes

Attention to work progress during new construction or renovation is important.

Other trades and cleaning services may use agents for ceramics and tiles that will damage these components.