

ASSEMBLY

This appliance must be used in accordance with any prevailing electrical code and relevant electrical wiring rules and regulations and in particular those regulations that cover use of appliances and accessories in damp situations such as bathrooms, showers, laundries and other areas with fixed water containers.

- Your Warmrail comes complete with all the mounting hardware you require, which includes 8 screws, 8 wall anchors, 4 wall brackets, 4 bracket covers and 4 locking screws.
- Position the four bracket covers on the Heated Towel Rack (refer to the diagram).
- Insert wall brackets attachments (the pieces with two screw holes) into the four mounts on the unit and secure in place by inserting locking screw through the hole you will see at the top of each of the mounts (if you can't see the holes, you have the unit up-side down).
- With the wall brackets now firmly attached, hold the Heated Towel Rack against the wall at the location you would like it to be installed.
- Use a pencil or pointed tool to mark the location of the screw holes spaces onto the wall through the screw holes in the wall brackets. Put the Heated Towel Rack aside and drill pilot holes through the marks you have made on the wall.
- Where a stud is conveniently located, you can just use the screws to attach the wall bracket. For the remaining wall brackets, use the wall anchors supplied to firmly anchor the screws into the dry wall.
- Push the anchors into the dry wall (you may need to make larger pilot holes where the wall anchors are located).
- Put the screws through the holes in the wall brackets, then hold the Heated Towel Rack back in position on the wall.
- Tighten the screws until the wall brackets are flush against the wall. Gently push the bracket covers towards the wall to cover the wall plate.
- Once securely attached to the wall, the unit can be plugged into an electrical outlet (we recommend using a GFI protected outlet) and your Warmrail is ready for use. Please note, the Regent must be installed with the power entry coming out from the bottom right hand side of the unit.



SAFETY INFORMATION

When using any electrical appliance, basic safety precautions should always be observed.

READ THESE INSTRUCTIONS CAREFULLY

- Do NOT use this appliance for other than its intended use.
- To avoid a hazard, the Heated Towel Rack MUST NOT be used to hold towels or any other articles that have been in contact with oil, petroleum based products or dry cleaning fluids.
- Use this appliance only on the voltage specified on the rating plate, or elsewhere in the instructions.
- Regulations require that only authorized persons carry out electrical work. For your own safety and that of others, ensure this is done.
- Do NOT store your Heated Towel Rack while hot or still connected to the power supply.
- Do NOT immerse the Heated Towel Rack in water or any other liquid.
- Do NOT allow the cord set to come into contact with heated surfaces during operation.
- This product should NOT be used outdoors.

If the power supply cord for this equipment becomes damaged it must be replaced with the special cord or assembly. Special tools are required for the replacement of the power supply cord and element. A qualified electrician must undertake this replacement.

WARNING

HIGH OPERATING TEMPERATURE:

- This towel warmer operates at high temperatures that can cause burns.
- Do not touch surfaces of the towel warmer while the warmer is in operation.
- Do not allow unsupervised children in the vicinity of the towel warmer; and Warn children of hot surfaces

TO AVOID THE POSSIBILITY OF ELECTROCUTION:

- Do not immerse towel warmer in water or any other liquid
- Do not place towel warmer in a location where it may fall into a tub or shower, or otherwise become immersed in water; and if the towel warmer falls into water, immediately unplug it. Do not reach into the water.

SPECIFICATIONS

| HEIGHT | WIDTH | DEPTH |
|---------|---------|--------|
| 25 1/4" | 19 1/8" | 5 1/4" |

Supply: 120 volts a.c. 60 Hz, single phase