

MAILBOX INSTALLATION

POST MOUNT MAILBOXES

Mailbox mounted on a Pole

Each post mount mailbox has four holes positioned to match all Streetscape mailbox poles.

The mounting holes are centered on the bottom of the box 5 1/2" front to back and 5 1/4" side to side.

Four 3/4" stainless machine screws with nuts and washers are provided with each mailbox.

- 1) Set mailbox in place aligning mailbox holes to holes in support plate.
- 2) Insert screws in large washers then insert screws through mailbox holes from the inside.
- 3) Secure split lock washers and nuts to screws from under the support plate.
- 4) Tighten using 5/32" Allen wrench inside mailbox, and pliers to hold nut.

NOTE: The Oxford mailbox install is the same except the hole pattern is 8 1/2" front to back and 7 1/4" side to side (Oxford is designed for use with the SI-223SX only).

Mailbox mounted on wood Pole

A 4" X 4" wood post with 1 1/2" to 2" cross boards is the most common style.

The holes should align near the center of the cross boards.

Four 1 1/4" X 1/4" stainless hex head lag bolts with large washers are suggested.

(Mark and pre drill holes to avoid splitting wood)

WALL MOUNT MAILBOXES

Each wall mount mailbox has two holes positioned at the top corners of the back of the mailbox.

Two 1 1/4" stainless screws with 1" #10 plastic screw anchors and washers are provided with each mailbox.

- 1) Position mailbox in desired location and mark wall through the center of mounting holes.
- 2) Drill both holes in wall 1" deep using 1/4" drill bit.
- 3) Insert plastic screw anchors into holes.
- 4) Insert screws into washers.
- 4) Align mailbox to anchors in wall, insert screws and tighten.

RECESSED MAILBOXES

Each recessed mailbox installation presents a unique installation application.

It is suggested that the person or contractor in charge of designing the recessed cavity call Streetscape

if they would like assistance. Below are some general guidelines.

- 1) Contractor should have the mailbox before building the cavity.

- 2) Mailbox should be slid into cavity and secured - IT SHOULD BE REMOVABLE.
- 3) The outer frame of the mailbox should be recessed as well to shelter from water/rain.

MAILBOX POLE INSTALLATION


METHOD 1 - Using prefabricated installation base (not included).


INSTALLATION BASE

Dimensions: 3"H X 12"W with 4 anchor bolts

Model Number: SI-014







STEP #1

Mark pole center location 20" behind curb face. Mailbox door will be 9 1/2 to 11" behind curb face.

(Confirm distance with postal carrier)

STEP #2

Dig hole using installation base as imprint on ground (see drawing).

STEP #3

Insert installation base in hole. Confirm base is level and 1" above surface. Remove installation base.

STEP #4

Mix concrete and fill hole to 1 1/2" from top. (Caution: quick setting concrete may set too fast).

STEP #5

Insert installation base in hole. Level base and adjust anchor bolts to parallel with curb. Allow concrete to set.

STEP #6

Mount mailbox pole to base. Use back access door for large base. (Mailbox on left).

STEP #7

Mount custom address sign and base cover (if applicable), then mount mailbox.

METHOD 2 - Using all poured concrete.

Cumming soon