

Limited Warranty Information

Thank you for choosing an Alpine product! We aim to please with our wide range of products including Solar Lighting, Fountains, Birdbaths, Statuary, and Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect.

Please read below for a detailed description of warranty coverage.

- **Water Damage**

Alpine products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage, is considered negligence, and will not be covered under this warranty. The use of "hard water," and/or caustic cleaners, can affect the painted or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of Alpine Corporation.

- **Paint & Color (Retention and/or Loss)**

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading, within the first year from date of purchase, with the above exclusion.

- **Procedure/Service**

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. If that not an option, you can contact Alpine Corporation at www.alpine4u.com. When contacting Alpine Corporation, you must be prepared to show proof of purchase, provide photographs, and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department.

- **Not Covered Under Warranty**

The limited warranty will NOT cover cases of damages due to:

1. Damages caused in Transit
2. Inadequate care and/or neglect
3. Environmental and/or natural elements
4. Immersion in water, unless specified
5. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim



SLA308 Series Stainless Steel Low Voltage Light




Inserting and Assembling Luminosity™ Light

Before reading instructions below, this light **MUST** be used with a Quick Connect Cable and transformer. *Recommended to use light fixture with an Alpine Quick Connect Cable and transformer.*



Assembly:

STEP 1: Assemble the Luminosity™ light fixture as shown in the diagram to the right.

STEP 2: Decide on a desirable place to stake Luminosity™ light. Be sure the desired location is debris/rock free and is at least 10ft. away from pools, spas or fountains. Loosen and soften the dirt with a shovel or by adding water.



STEP 3: Insert the stake of the Luminosity™ Light fixture into the ground by pushing the stake gently into the ground. To avoid damage to your Luminosity™ light fixture, do not use a hammer or push down from the top of the light pressure. Plug the Luminosity™ light fixture into a Quick Connect Cable (sold separately). Please see diagram below for details.



1
Mount/ position outdoor transformer



2
Route low voltage cable



3
Connect fixtures to Quick Connect Cable

Using Your Luminosity™ Lights the First Tim

- Before plugging in the unit, be sure the input voltage indicated on your transformer is the same as your local power supply. If not, please do not operate the light until you obtain the appropriate transformer from your local dealer.
- To reduce the risk of electrical shock, inspect all cords for damage before installation.
- Plug the connector of the Luminosity™ Light into the socket on the transformer or Quick Connect Cable and screw the coupling until tight. Plug the transformer into the nearest 120-volt outlet. Your Luminosity™ Light should light up.

If Your Luminosity™ Light Fails to Illuminate

- Check that the light set is getting power by testing another applicant in the power outlet that the lights use.
- Check to ensure that your light bulb has not burned out from usage.
- If water gets into any of your Luminosity™ Lights, lift it out of water, remove the lampshade, and empty the water until dry.



Caution: Risk of fire or electrical shock

- This product is not a toy and must not be operated by children.
- To connect to the main low voltage cable, the low voltage cable should be buried 6 inches maximum.
- Do NOT connect the low voltage cables with wet hands.
- Must be used with low voltage landscape lighting equipment.
- Do NOT exceed the voltage and wattage indicated on the transformer.
- Do not assemble this product with submersible or pool/spa equipment.
- Do NOT install within 10 feet of pools, spas or fountains.
- Store the unit in a dry place if not in use for an extended period of time.