





Step 1.

Align the pins in the leg with the pre-drilled holes in the under side of the top. Lower into place and tighten the connectors clockwise with a #2 Phillips screwdriver.




Step 2.

Secure leg brackets in place with the 16mm Euro screws provided.



Step 3.


Insert bolt through the laminate brace and the angle iron. Thread nut provided on to the bolt.



Step 4.


Using a 5/32 Allen key and a 1/2 wrench tight the nut and bolt securely.

Do this for both sides of the leg.



Step 5.


Align the holes in the inside leg with the pins in the leg braces and slide into place.




Step 6.

Tighten the connectors clockwise with a #2 Phillips screw driver.

Do this for both sides of the leg.




REPEAT 1-6 FOR SECOND LEG





Step 7.

Slide the laminate braces into place.



Step 8.

Secure the laminate braces in place with the 8x5/8 screws provided.



Assembly complete.

Turn table to upright position and install access doors on legs.

