



Shade Tech® Set-Up and Safety Instructions

Please read completely before setting up your Shade Tech® Instant Canopy

It is your responsibility to read and save these instructions before attempting to set up your Shade Tech® Instant Canopy. We would also like to suggest that you follow these safety precautions, care and maintenance tips when using your Shade Tech®:

1. Never set up or continue to use in any rain, wind or storm conditions, especially lightning storms. Damage can occur to your Shade Tech® and put you and others in potential danger.
2. We suggest that you take your time to avoid bending the frame or pinching your fingers or hands while opening or closing the frame.
3. Avoid setting up your Shade Tech® on steep inclines.
4. Always use the provided stakes to secure your Shade Tech® to the ground unless you set up on concrete or asphalt.
5. Do not use your Shade Tech® for permanent shelter. It was designed for temporary use only.
6. Keep your Shade Tech® canopy away from heat and flames at all times. Do not barbecue or build fires under you Shade Tech®.
7. Never leave your Shade Tech® unattended.
8. Hand wash the canopy using only mild soap and water. Never use harsh detergents, abrasives and/or bleach, etc. Do not machine wash.
9. Never fold or store your Shade Tech® when it is wet or damp. Let it dry completely to avoid mildew.
10. **ALWAYS USE COMMON SENSE.**

If you have any questions about your Shade Tech® Instant Canopy, please call our customer service representatives at (800) 248-5327.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame resistant properties ineffective.

Do not call store regarding set up issues, missing parts or any questions. Instead, please contact Bravo Sports directly at 800-248-5327.



©2007 Bravo Sports. All Rights Reserved.
U.S. Patent #4,779,635
Bravo Sports, 12801 Carmenita Rd, Santa Fe Springs, CA 90670
Customer Service Dept. Phone (800) 248-5327
E-mail: consumer@bravosportscorp.com Check us out at www.bravosportscorp.com

Limited Warranty

Subject to the following limitations, in addition to any imposed by virtue of applicable law, Bravo Sports warrants this Shade Tech® Canopy to be free of defects in material or workmanship for a period of 30 days from the date of original purchase. This warranty is limited to the repair and/or replacement of defective parts only.

1. This Limited Warranty will apply only if the Shade Tech® and/or its parts are properly returned to the Bravo Sports customer service department listed below and are determined by Bravo Sports in its sole discretion, to be defective.
2. This Limited Warranty applies only to Bravo Sports Shade Tech® Multi-Purpose Canopies purchased from authorized dealers. This Limited Warranty is extended only to the original consumer purchaser and is not transferable.
3. Be sure to retain your original purchase sales receipt for any warranty claim. All warranty claims must be accompanied by the original purchase receipt from the authorized dealer.
4. Before returning any Shade Tech® Canopy and/or parts to Bravo Sports for warranty inspection, the consumer purchaser must obtain prior authorization from Bravo Sports. Such authorization can be obtained by calling our customer service representatives at the toll-free numbers listed below or writing to the Bravo Sports customer service department at the address listed below. Customer is responsible for shipping costs.
5. Certain regions of the country have environmental conditions that are extremely hard on covers of any kind. If you live in Arizona, Florida, Nevada, New Mexico, Texas, or in high altitudes [above 3000 feet], the warranty period for your canopy top will be limited to 15 days from the date of original purchase. [After expiration of that 6 month period and up to a period of one year following date of original purchase, you may purchase a replacement canopy top at a reduced price from our customer services' department.]
6. This Limited Warranty does not cover damage or loss from: wind, rain, fire, snow, ice, or other forces of nature; accident; normal wear; improper assembly, disassembly, or adjustment during set-up or take-down; or any abuse, neglect or misuse of this Shade Tech® Canopy and/or its parts.
7. To the extent allowed by applicable law, any implied warranty of merchantability or fitness applicable to this Shade Tech® Canopy is limited to the duration of this Limited Warranty. Bravo Sports does not warrant against, and in no event shall Bravo Sports or its authorized agents be liable for, any personal loss, injury, or direct or indirect incidental or consequential damage resulting from the use of this product. Please note that some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This Limited Warranty gives you specific legal rights and you may have other rights which vary from state to state.
8. Upon receipt of authorization from our customer service department, you must submit your warranty claim to the address below, shipped prepaid and accompanied by the original dated purchase receipt. Do not return this product to the place of

purchase. For warranty service, or for missing parts, replacement parts or any other problems, call or write to our customer service department below. We will send any replacement parts via Fed - Ex.

Shade Tech® Set-Up and Safety Instructions

Do not call store regarding set up issues, missing parts or any questions. Instead, please contact Bravo Sports directly at 800-248-5327.

Before proceeding with the assembly of your Shade Tech® Instant Canopy, please make yourself familiar with its parts and how they make your Shade Tech® function.

The following parts are inside your Shade Tech® box:

1 Shade Tech® Assembled Frame

1 Canopy Top

1 Wheeled Bag*

Set Up

Step 1

Place your Shade Tech® in the center of the set-up area. With a partner on the opposite side of the frame, hold onto the two outer legs and lift slightly for clearance. Take a few steps backward until you have extended the frame a full arm's length - approx. 4 feet (figure A). To improve the opening and closing action of your Shade Tech®, spray some silicone lubricant on the outer legs.




Step 2

Place the canopy over the top of the frame (fig. B). Use the hook and loop straps to secure each corner of the cover to the frame under the plastic caps or steel bracket (fig. C).



Step 3

Hold the bottom of the middle frame section where it forms a "V" and says "OPEN" (fig. D). Lift slightly and slowly walk backward until the frame is fully extended (fig. E). Take care to avoid pinching your hands or fingers.



Step 4

At each corner, hold the leg of the frame with one hand and lift the slider with the other hand. Push the locking button in while pulling the slider up until the button pops through (fig. F). For the commercial series, sliders will lock in place as shown (fig. G).



Step 5

Secure remaining side hook and loop straps to the frame (fig. H). The adjustable legs offer multiple height levels. Simply lift a leg and adjust the inner leg up or down until the button pops into place (fig. I). Repeat on the other legs.



Final



Take Down

Note: The canopy top may remain in place for easier subsequent set-up, however, to prolong the life of the canopy top, we recommend that you remove it during take-down.

WARNING: Before storing your Shade Tech®, be sure the canopy top is not wet or damp. Storing your Shade Tech® while it is even slightly damp may cause mildew. Allow your canopy top to completely dry before taking it down. If you must take down your Shade Tech® while the canopy top is damp, remove the canopy top from the frame by unfastening the hook and loop straps. Fold up the frame and lay the canopy top down, fully open, as soon as possible and allow it to completely dry.

Step 1

Reduce each leg to its shortest position (fig. I).



Step 2

At each corner, push in the locking button and pull the slider down slowly until the button pops out above the slider (fig. J). For commercial units, pull ring out and move sliders down (fig. G).



Step 3

Hold the top of the middle frame section where it says "CLOSE" (fig. K). Lift slightly and slowly walk towards partner as the frame folds in. Keep walking until the frame is about halfway closed. Be sure to avoid pinching your hands or fingers. Hold outside legs and continue closing canopy as you walk towards your partner. The completely folded canopy should stand up on its own (fig. L).



Step 4

With the canopy standing, unzip the wheeled bag (loosen cord for WX8) and slide bag down slowly (fig. M) until entire canopy is in. Invert the canopy and zipper shut (fig. N).



If your canopy came with a polyethylene top, please remove this before inserting the frame into the bag.



Wheeled Bag

